

SUPER JX JX-10

SERVICE NOTES *First Edition*

SPECIFICATIONS

Keyboard : 76 key, (E to G)

Memory Capacity

- a. Patch Memory
Internal Memory : 64
Memory Cartridge : 64

b. Tone

- Preset : 50
Internal Memory : 50
Memory Cartridge : 50

c. Sequencer Data

(Using the supplied Memory cartridge M-16C or M-64C)

M-16C : Approx. 400 notes

M-64C : Approx. 1600 notes

Output:

- MIX H = $8K\Omega$, +20dBm max.
M = $41K\Omega$ +5dBm max.
L = $47.8K\Omega$ -10dBm max.

UPPER L $3.3K\Omega$

R $3.3K\Omega$

LOWER L $3.3K\Omega$

R $3.3K\Omega$

HOLD PEDAL OFF : 0V ; ON : 5V

PEDAL SW OFF : 0V ; ON : 5V

C1, C2 0V - 2.5V

Dimensions: 1186 (W) x 375 (D) x 101 (H) mm

46-11/16 x 14-3/4 x 4 in.

Weight: 14 kg/30 lb. 14 oz.

Power Consumption : 28W

Accessories

Connection Cord x 2

Memory Cartridge

M-16C x 1

M-64C x 1

Edit Map

Music Rest

Owner's Manual

MIDI Guide Book "MIDI"

Options

Programmer PG-800

Expression Pedal EV-5

Pedal Switch DP-6, DP-2

Memory Cartridge M-16C, M-64C

Carrying Case






TABLE OF CONTENTS

EXPLODED VIEW

PARTS LIST

BLOCK DIAGRAM

CIRCUIT DESCRIPTION

TEST MODE

ASSIGNER BOARD

CARTRIDGE BOARD

MODULE BOARD

ADJUSTMENT

VOLUME BOARD

SWITCH BOARD

DISPLAY BOARD

KEYBOARD PCB

JACK BOARD

POWER SUPPLY BOARD

MIDI

CHANGE INFORMATION

目次

分解図

パーツリスト

ブロック図

回路解説

テストモード

アサイン基板

カートリッジ基板

モジュール基板

調整

ボリューム基板

スイッチ基板

ディスプレイ基板

鍵盤部基板

ジャック基板

電源基板

MIDI

変更案内

Page

2

3

4

5

5

6-7

7

8-9

9

10

10-11

10-11


11

12

12

12-13


14



*: PANEL REMOVAL SCREWS

LETTER	DESCRIPTION	PART NO.	LETTER	DESCRIPTION	PART NO.
(A)	3 x 16mm RH BLK with Washer		(I)	Assigner Board Assy	7616510000
(B)	Rubber Foot	22355129	(J)	Display Board Assy	7616529000
(C)	4 x 16mm Truss BLK		(K)	Module Board Assy (LOWER)	761657000
(D)	4 x 16mm Truss BLK		(L)	Module Board Assy (UPPER)	
(E)	3 x 12mm Binding Bayonet		(M)	Power Supply Board Assy	7616516100 100/117V 7616516400 220V 7616516500 240V
(F)	Volume Board Assy	7616530000	(N)	Head Sink	22463487
(G)	Jack Board Assy	7616519000	(O)	Power Transformer	2245344300
(H)	Switch Board Assy	7616528000	(P)	Sub Heat Sink	22463488

22575216	NATURAL KEY C, F 257-216	8	22155716	GUIDE BUSH
22575214	NATURAL KEY D 257-214	9	22185218	KEY SWITCH 12P 218-218
22575217	NATURAL KEY E, B 257-217	10	22245146	SWITCH COVER 224-146 (24P)
22575215	NATURAL KEY G 257-215		22245147	SWITCH COVER 224-147 (28P)
22575213	NATURAL KEY A 257-213		7616522000	KEY SWITCH ASSY 24P LOW
22575219	NATURAL KEY E' 257-219	11	7616523000	KEY SWITCH ASSY 24P MID
22575220	NATURAL KEY G' 257-220		7616524000	KEY SWITCH ASSY 28P HI
22575212	SHARP KEY 257-212	12	22035131	STAND B-JX 203-131
22175176	KEY SPRING 217-176 (NATURAL KEY)	13	22125541	ANGLE B-JX 212-541
22175177	KEY SPRING 217-177 (SHARP KEY)	14	22035130	STAND A-JX 203-130
22815521	CHASSIS 281-521	15	22125542	ANGLE A-JX 212-542
22265452	FELT 226-452	16	22135415	STOPPER A 213-415
23165664	AFTER TOUCH ASSY		22135418	STOPPER D 213-418
22265453	FELT 226-453			



PARTS LIST

PANEL, CASING	
22213498	Top Panel
22213756	Bender Panel
21133147	Bottom Board
22233325	Blind Panel
21123228	Side Panel (left)
21123229	Side Panel (right)
22123197	Plate
22123550	Angle (Same for both R, L)

KNOB, BUTTON	
22485103	Slide Pot., switch (Bender panel)
22485102	Knob
22473775	Keypot Assy A (MASTER TUNE, WRITE)
22473776	Keypot Assy B (CART → INT, CART ← INT)
22473777	Keypot Assy C (PATCH, TONE, MIDI)
22473778	Keypot Assy D (PALAM, VALUE, NAME)
22473779	Keypot Assy E (PEDAL SWITCH, C1, C2)
22473780	Keypot Assy F (DUAL, SPLIT, WHOLE)
22473781	Keypot Assy G (TEN KEYS, ENTER)
22473782	Keypot Assy H (RECALL, FUNCTION DISPLAY)
22473783	Keypot Assy I (← LOWER, UPPER →)
22473784	Keypot Assy J (FUNCTION, TIME, ON/OFF)
22473785	Keypot Assy K (A B C)
22473786	Keypot Assy L (1 2 3)
22473787	Keypot Assy M (D E)
22473788	Keypot Assy N (4 5)
22473789	Keypot Assy O (F G H)
22473790	Keypot Assy P (6 7 8)
22473792	Keypot Assy Q (REC, FUNCTION, START/STOP)

SWITCH	
13159509	EMA-NAM X15 300 (Portamento ON/OFF Bend range select)
13159335	SSSF122A04 (Output level, Memory protect)
13129704	SKH CAB 131A (All key switches)
13279792	EC 16B 40B (Rotary encoder for dial)
13149108	WK2A44 3A (Power)

JACK, SOCKET	
13449146	YKB21-5012 (MONO)
13449145	YKB21-5010 (STEREO)
13449252	YKB21-5006 (STEREO)
13429168	MID13-NS (5P DIN, triplet)
13429621	TCS5360-01-1111 (6P DIN, programmer)
13429710	AC Inlet PA-126 (100/117/220V)
13429708	AC Inlet CM-3 (240V)

MEMORY CARTRIDGE SOCKET	
23425803	SHELL (Black)
23425165	PBR5-280-T01-S (Socket)

POWER TRANSFORMER	
2245344300	245-44300

COIL	
12449251	DC-DC Converter
12449244	SC-02-15E (Line filter)

RESONATOR	
12389737	HC/U 16MHz (Crystal)
12389748	CSB600P (Ceralock)

PCB ASSY	
7616510000	Assigner Board
7616507000	Module Board
7616516200	Power Supply Board (100/117V)
7616516400	Power Supply Board (220/240V)
7616519000	Jack Board
7616528000	Switch Board
7616529000	Display Board
7616530000	Volume Board

POTENTIOMETER	
13339455	EMA-NFE X15 B14 (Slide Pot.)
13359354	EMA-NAO X15 D54 (Slide Pot.)
13339461	EMA-NFD X15 B14 (Slide Pot.)
13299193	EVN-D4A A00 B54 (Trimmer)
13299199	EVN-D4A A00 B13 (Trimmer)

IC	
15229830	MB63H149PF-C-BND (Dynamic gate array)
15179334	TC5564 PL-20 (C-MOS static RAM)
15179343FD	MB8416A-12-SK-G (C-MOS static RAM)
15179733	TC27256 D-20-733 (ROM A Assigner board)
15179732	MNM2764-25Z-732 (ROM B LOUER Module board)
15179745	MNM2764-25Z-745 (ROM C UPPER Module board)
15179203	HD63B03BP (CPU on assigner board)
12519150	μPD7001C (8-bit A/D converter)
15179142F0	MBL8031AH-P-G (CPU on Module board)
15179358	μPD8155HC-2 (8-bit static RAM)
15179185B0	MSM82C54 P-6-D-I (Programmable counter)
15219149	MMS437 (Digital noise source)
15159503	TC40H000P (C-MOS Inverter)
15159524	TC40H245P (C-MOS Driver)
15159511	TC40H174P (C-MOS D-FF)
15159508	TC40H373P (C-MOS Latch)
15169301B0	M74LS00 (Quad NAND)
15169304B0	M74LS04 (Hex inverter)
15169308B0	M74LS30 (8-input NAND)
15169347B0	M74LS32 (Quad OR)
15169311B0	HD74LS74 (Dual D-FF)
15169318B0	M74LS138 (Decoder)
15169325B0	M74LS273 (8 D-FF)
15169327B0	M74LS367 (Hex buffer)
15169305B0	M74LS08 (Quad 2-input AND)
15169321B0	M74LS161 (Counter)
15159128T0	M74LS00BP (Hex buffer)
15159114T0	TC4052BP (Analog switch)
15159115T0	TC4066BP (Quad analog switch)
15159113D0	BU4051BP (Analog switch)
15159124	HD14093 (Quad 2-input NAND)
15179240	μPD7538A-013 (Display 4-bit CPU)
15219159	μPD6300C (FIP latch driver)
15189171	M5218P (OP amp)
15189154J0	NJM064 (Quad op amp)
15219213	MN-3009 (BBB)
15169504	MN-3101 (BBB Driver)
15219157	M5241L (VCA for electronic volume)
15189136	M5218L (OP amp)
15229826	1R-3B05 (VCF-VCA Pack)
15199117	M5230L (V-regulator)

TRANSISTOR	
15119106	2SA733Q
15129107	2SC945Q
15119814	2SB1015-O
15129827	2SD1406-O
15119601	2SB605L
15129130G	2SC1583G
15129613	2SD1207S
15119819	2SB507E
15129820	2SD313E
15129170	2SC945R
Qm selected for Q6, Q7, Q10 of Module board VCF/VCA module; dotted in Red, Orange, Yellow or Green. 18 2SC945R (3 for each voice) on a given Module board should be of the same color dot for reproducing uniform timber.	

15139103	2SK30A-GR
15119133	DTA114EF (Digital transistor)
15129150	DTC114EF (Digital transistor)

DIODE, LED, PHOTO COUPLER	
15019125	1SS-133
15019143	1S-116
15019603	0529.1Z
15019605	05243Y
15019607X	05X6.2X
15029718	FIP 32B 6R (Fluorescent indicator)
15029206	CL3HD5 (LED)
15229706	TLP-552 (Photo coupler)
15019208	1SR-35-200 (Diode n Power supply board)
15019243	1B4B1 (Rectifier bridge)
15019257	4D8B41 (Rectifier bridge)

RESISTOR	
13919313	RMLS 8-104J (100k x8 array)
13919321	RMLS 13-103J (10k x 3 array)
13919310	RMLS 8-103J (10k x 1 array)
13919308	RMLS 6-103J (10k x 1 array)
13919147	RMLS 4-103J (10k x 1 array)
13919335	RGLD 6-102J (1k x 6array)
13919146	RKM 14L 503F (R-28 DA array)
13919168	RMLS 4-224J (220k x1 array)
13919336	RMLS 8-224J (220k x8 array)
13919322	RMLS 4-102J (1k x 4array)

CAPACITOR		
13529104	DE7150F472MVA1	(Line bypass)
13549216Y0	0.01μF 50V, G (±2%)	(Film)
13529116	DD107SL221G50V	(220pF, 50V)
13529128	DD107CH680J50V	(68pF, Temperature compensating)

FUSE, FUSE HOLDER		
12559336	CGS 2A	(100/117V)
12559513	CEE T1A	(220/240V)
12199552	UF0005-02	(Fuse holder)

CONNECTOR HOUSING		
13439263	5267-06A	
13439264	5267-07A	
13439265	5267-08A	
13439269	5267-09A	
13439278	5267-11A	
13439267	5267-12A	
13439266	5267-10A	
13439261	5267-04A	
13439285	5268-03A	
13439318	5268-11A	
13439273	5268-06A	
13439271	5268-02A	
13439272	5268-04A	
13439270	5268-08A	
13439280	Card fitting CF-028	(Sumi card connector)
13439315	Card fitting CF-034	(Sumi card connector)
13439316	Card fitting CF-127	(Sumi card connector)
13439317	Card fitting CF-134	(Sumi card connector)

AC CORD, CORD SET		
13439801	PVFF 2.5m	(100V)
12369504	Cord bush SR-4N-4	(100V)
12913842	Cord holder	(100V)
13439812F0	VC-704-J01	(117V)
13439813P0	EC-210-J01	(220V)
13439814P0	SC-415-J06	(240V 3P, Australian)
13436846	BH-301-J01	(240V 3P, England)

COVER		
22023730	FCD cover	
22253118	Bender shield cover	
22253122	Shield cover	
22243143	Slide volume cover 224-143	
22673503	Cover 267-503	(Heat sink)
22023736	LED cover 202-736	

COLLAR, BUSHING		
12159713	Collar TA-305	(5mm)
12159734	Collar TA-307	(7mm)
12159733	Collar TA-310	(10mm)
12159715	Bushing TB-300	

FLAT CABLE		
13479189	Sumi card SMCD 28 x 700-BD10P1.25	
13479184	Sumi card SMCD 34 x 250-AD x 10	
13479185	Sumi card SMCD 27 x 100-AD x 10	


HEAT SINK		
22463487	246-487	
22463488	Sub 246-488	
22465124	246-124 (Rectifier 4D4B41)	

WIRING		
23493388	A	
23493389	B	
23493390	C	


CUSHION		
22263366	Cushion A	
22263367	Cushion B	
22263368	Cushion C	

MISCELLANEOUS		
22223314	Escutcheon (dial)	
22223315	Escutcheon (FCD cover)	
22193621	Music Rest	
22155735	Bush 215-735 (Music rest)	
22195389	Holder 219-389 (Music rest)	
22373607	Memory Cartridge M-16C (Sequencer data)	
22373608	Memory Cartridge M-64C (Sound backup)	
22393119	Edit map (Magnet sheet)	
12569252	Lithium Battery CR-2450	
13429523	IC Socket SMO-28-S6T	
12359105	Rubber foot G-7 weight	
12449266	Ferrite beads inductor BL01 RNL-A62 (EMI filter)	
23273795	Bender unit PB-11 (Black type)	
22150524	Boss nut #524 (H=8mm)	
22193830	Jack board holder 219-830	


BLOCK DIAGRAM



CIRCUIT DIAGRAM





1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39



ASSIGNER BOARD

76165100 00 (pcb22923303 03)


PARTS SIDE 部品面




SOLDER SIDE 半田面

CARTRIDGE BOARD

76165050 00 (pcb22923126 03)






PARTS SIDE 部品面

PARTS SIDE 部品面

CIRCUIT DIAGRAM



ADJUSTMENT

ADJUSTING VCF

1. Press and hold PATCH MEMORY B and C buttons and turn the power on. The JX-10 is now in the combination of test modes 2 and 3. During the mode each single key down is assigned a module indicated by a lighting LED as shown in Fig. C. The assignment is cyclic and will be disordered when more than one key is touched at a time. Should this happen, turn the power off then enter this mode again.

CAUTION
Allow at least 5 minutes for warm up before go to the para. 2.

2. Press EDIT, TONE button.
Edit the parameters (UPPER and LOWER) to the values listed in Fig. D from the front panel. Do not use PG-800 or programmer for this purpose. Keep the socket for the PG-800 on the rear panel unplugged.

3. Plug OUTPUT jacks:
oscilloscope to UPPER L (Mono)
dummy plug (open-circuited) to LOWER R (Mono)

4. Press the A key that generates 442Hz (A key above middle C).

5. Identify the modules being assigned to the key by watching the panel LEDs. Fig. C.
Adjust the trimmer of the module on UPPER module board for the maximum swing on the screen.

6. (Note that pressing the A key advances the module.) Repeat step 5 for the remaining modules of UPPER module board.

7. Replug the OUTPUT jacks:
dummy plug (open-circuited) to UPPER L (Mono)
oscilloscope to LOWER R (Mono)

8. Repeat steps 5 and 6 for the LOER modules.

NUMBER	PARAMETER	VALUE
11	DCO 1 RANG	8'
12	DCO 1 WF	SQUR
13	DCO 1 TUNE	00
14	DCO 1 LFO	00
15	DCO 1 ENV	00
41	MIX DCO 1	99
42	MIX DCO 2	00
43	MIX ENV	00
52	VCF FREQ	54
53	VCF RES	99
54	VCF LFO	00
55	VCF ENV	00
56	VCF KEY	00
61	VCA LEVEL	70
62	VCA MODE	GATE
64	CHORUS	OFF

Fig. D

EDIT	[	MIDI -----	MODULE	A
		TONE -----	MODULE	B
		PATCH -----	MODULE	C
KEY MODE	[	DUAL -----	MODULE	D
		SPRIT -----	MODULE	E
		WHOLE -----	MODULE	F

Fig. C

調整仕様

V C F

1 PATCH MEMORYの「B」、「C」ボタンを押しながら電源をいれる。(テストモード2、3のコンビネーションを立ち上げる。)

1つのキーを押すたびに、UPPER及びLOWER側から、Fig. CのLEDに対応したモジュールが順々にアサインされます。
[注意:複数のキーを同時に押すとアサインされる順序は乱れてしまいます。もし、乱れてしまった場合は、再度このモードを立ち上げて下さい。]

通電5分経過後に次のステップへ進んで下さい。

2 EDITの「TONE」ボタンを押す。
Fig. Dの音色パラメータをPG-800を用いずに、本体のみでアサインされます。
[注意:PG-800端子には、何も接続しないこと。]

3 OUTPUTジャックのUPPER L (MONO)にオシロスコープを、LOWER R (MONO)にダミージャック (オープン)を接続する。

4 A4 (442Hz) キーを押す。


5 現在アサインされている (パネルLEDに表示) UPPER側のモジュールの半固定VRを調整し、出力波形が最大になるようにする。

6 残りの5つのモジュールも同様に行う。(但し、A4キーをその都度押し直す。)

7 OUTPUTジャックの接続を下記のように入れ換える。
UPPER L (MONO) = ダミージャック
LOWER R (MONO) = オシロスコープ


8 LOWERモジュール・ボードの各モジュールをUPPER側と同様に調整する。

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39



SWITCH BOARD
76165280 00 (pcb22923298 01)


SOLDER SIDE 半田面




DISPLAY BOARD
76165290 00 (pcb22923301 02)

SOLDER SIDE 半田面


IC DATA




端子接続図 (Top View)




1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39




KEYBOARD PCB




(pcb 22925266-01)




(pcb 22925267-01)



(LOWER) (UPPER)



76165190 00 (p c b 22923297 01)



PARTS SIDE 部品面

POWER SUPPLY BOARD

100/117W 76165162 00 (p c b 22923299 00)

220V 76165164 00 (p c b 22923299 00)

240V 76165165 00 (p c b 22923299 00)

MIDI IMPLEMENTATION

[12 voice polyphonic synthesizer]

Date : Feb. 21 1986

Model JX-10

MIDI Implementation Chart Version :1.01

Function ...		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	UP:1-16 LO:1-16 UP:1-16 LO:1-16	UP:1-16 LO:1-16 LO:1-16 LO:1-16	memorized
Mode	Default Messages Altered	Mode 3 OMNI OFF, POLY *****	Mode 3 x	
Note Number	True voice	28 - 103 *****	0 - 127 21 - 108	
Velocity	Note ON Note OFF	o x 9n v=0	o v=1-127 x	
After Touch	Key's Ch's	x o	x *	
Pitch Bender		*	* 2/3/4/7 semi	8 bits reso.
Control Change	1	*	*	Modulation
	5	o	o	Portamento Time
	7	*	*	Volume
	64	*	*	Hold SW
	65	*	*	Portamento SW
Prog Change	True #	* 0-99 (0-127) *****	* 0-99 (0-127) 0-99 (0-127)	**
System Exclusive		*	*	
System Common	Song Pos Song Sel Tune	x x x	x x x	
System Real Time	Clock Commands	o When sequencer o cartridge is set	x x	
Aux	Local ON/OFF All Notes OFF Active Sense Reset	x o x x	o o (123-127) x x	Default ON
Notes		* Can be set to o or x manually, and memorized. ** As tone# : 0-99 (100-127 ignored if received). As patch# : 0-127 As optional Prog# (transmitted only) : 0-127 See each implementation notes for details.		

```

Mode 1 : OMNI ON, POLY      Mode 2 : OMNI ON, MONO      o : Yes
Mode 3 : OMNI OFF, POLY     Mode 4 : OMNI OFF, MONO     x : No

```


JX-10 MIDI IMPLEMENTATION

Ver 1.01 Feb. 21 1986

*** JX-10 MIDI IMPLEMENTATION ***
Version 1.01
Feb. 21 1986

1. TRANSMITTED DATA

Status	Second	Third	Description	
1001 nnnn	0kxx kxxx	0000 0000	Note OFF kkkkkkk = 28 - 103	
1001 nnnn	0kxx kxxx	0vvv vvvv	Note ON kkkkkkk = 28 - 103 vvvvvvv = 1 - 127	
1011 nnnn	0000 0001	0vvv vvvv	Modulation vvvvvvv = 0 - 127	*1
1011 nnnn	0000 0101	0vvv vvvv	Portamento time vvvvvvv = 0 - 127	
1011 nnnn	0000 0111	0vvv vvvv	Volume vvvvvvv = 0 - 127	*1,*2
1011 nnnn	0100 0000	0111 1111	Hold ON	*1
1011 nnnn	0100 0000	0000 0000	Hold OFF	*1
1011 nnnn	0100 0001	0111 1111	Portamento ON	*1
1011 nnnn	0100 0001	0000 0000	Portamento OFF	*1
1100 nnnn	0ppp pppp		Program Change ppppppp = 0 - 99 (0 - 127)	*1,*3
1101 nnnn	0vvv vvvv		Channel After Touch vvvvvvv = 0 - 127	
1110 nnnn	0vvv vvvv	0vvv vvvv	Pitch Bender Change	*1
1011 nnnn	0111 1011	0000 0000	ALL NOTES OFF	*4
1011 nnnn	0111 1100	0000 0000	OMNI OFF	*5
1011 nnnn	0111 1111	0000 0000	POLY ON	*5
1111 1000			Timing clock	*6
1111 1010			Start	*6
1111 1100			Stop	*6

Notes :

Normally, transmitting channel depends on UPPER/LOWER CHANNEL and KEY MODE.
If MIDI SEND OPTION UPPER/LOWER CHANNEL and MIDI SEND OPTION KEY MODE is set, channels are followed to its settings.

*1 Transmitted if the corresponding function switch is ON.

*2 a. When 'C1' or 'C2' slider is assigned as VOLUME, and moved :
The value is transmitted if the corresponding function switch is ON.

b. When PATCH # is changed :
MIDI SEND OPTION VOLUME is transmitted if it was set.

*3 a. When TONE # is changed :
TONE # is transmitted if the corresponding function switch is ON.
ppppppp = 0 - 99 : TONE No. 1 - 100

b. When PATCH No. is changed :
TONE # for new PATCH is transmitted. (See note a.)
If OPTION PROGRAM CHANGE NUMBER is set, the Number is transmitted instead of TONE #.
ppppppp = 0 - 127 : PROGRAM CHANGE NUMBER 1 - 128
If PATCH MEMORY CHANNEL is set, PATCH # is transmitted to PATCH MEMORY CHANNEL, after transmitting TONE # (or OPTION PROGRAM CHANGE NUMBER).
ppppppp = 0 - 63 : Internal Memory PATCH A1 - H8
64 - 127 : Cartridge Memory PATCH A1 - H8

*4 When all keys on the keyboard are released, this message is sent.

*5 When power is first applied while MIDI button being held down, these messages are transmitted for all channels (1-16).

*6 When the CARTRIDGE - that stores sequence data - is set.

2. RECOGNIZED RECEIVE DATA

Status	Second	Third	Description	
1000 nnnn	0kxx kxxx	0vvv vvvv	Note OFF, velocity ignored	
1001 nnnn	0kxx kxxx	0000 0000	Note OFF kkkkkkk = 0 - 127 (21 - 108) *1	
1001 nnnn	0kxx kxxx	0vvv vvvv	Note ON kkkkkkk = 0 - 127 (21 - 108) *1 vvvvvvv = 1 - 127	
1011 nnnn	0000 0001	0vvv vvvv	Modulation vvvvvvv = 0 - 127	*2
1011 nnnn	0000 0101	0vvv vvvv	Portamento time vvvvvvv = 0 - 127	
1011 nnnn	0000 0111	0vvv vvvv	Volume vvvvvvv = 0 - 127	*2

1011 nnnn	0100 0000	01xx xxxx	Hold ON	*2
1011 nnnn	0100 0000	00xx xxxx	Hold OFF	*2
1011 nnnn	0100 0001	01xx xxxx	Portamento ON	*2
1011 nnnn	0100 0001	00xx xxxx	Portamento OFF	*2
1100 nnnn	0ppp pppp		Program Change vvvvvvv = 0 - 127 (0 - 99) *2,*3	
1101 nnnn	0vvv vvvv		Channel After Touch vvvvvvv = 0 - 127	*2
1110 nnnn	0vvv vvvv	0vvv vvvv	Pitch Bender Change	*2
1011 nnnn	0111 1010	0000 0000	Local OFF	*2
1011 nnnn	0111 1010	0111 1111	Local ON	*2
1011 nnnn	0111 1011	0000 0000	ALL NOTES OFF	*2

Notes :

All messages except PATCH# (Program Change) are received from UPPER and/or LOWER CHANNEL according to KEY MODE.

*1 Note numbers outside of the range 21 - 108 are transposed to the nearest octave inside this range.
*2 Received if the corresponding function switch is ON.

*3 a. When PATCH MEMORY CHANNEL is OFF :
Received as TONE # if the corresponding function switch is ON.
ppppppp = 0 - 99 : TONE No. 1 - 100
b. When PATCH MEMORY CHANNEL is set :
Received as PATCH #, from PATCH MEMORY CHANNEL.
ppppppp = 0 - 63 : Internal Memory PATCH A1 - H8
64 - 127 : Cartridge Memory PATCH A1 - H8

3. HANDSHAKING COMMUNICATION

* How to enter to 'DUMP' or 'LOAD' mode :
1. Press bulk MIDI and WRITE button.
2. Select DUMP or LOAD by ALPHA-DIAL, then press ENTER.

* Exclusive messages are transmitted and received if SYSTEM EXCLUSIVE (MIDI FUNCTION #11) is ON.

3.1 Message type

3.1.1 Want to send a file (WSF)

Byte	Description
a 1111 0000	Exclusive status
b 0100 0001	Roland ID #
c 0100 0000	Operation code = WSF
d 0000 nnnn	Unit # = UPPER MIDI basic channel, nnnn = 0 - 15 where nnnn = 1 = channel #
e 0010 0100	Format type (JX-10)
f 0111 ffff	File name (1 byte)
g 0xxx ssss	Check sum
h 1111 0111	End of System Exclusive

3.1.2 Request a file (RQF)

Byte	Description
a 1111 0000	Exclusive status
b 0100 0001	Roland ID #
c 0100 0001	Operation code = RQF
d 0000 nnnn	Unit # = UPPER MIDI basic channel, nnnn = 0 - 15 where nnnn = 1 = channel #
e 0010 0100	Format type (JX-10)
f 0111 ffff	File name (1 byte)
g 0xxx ssss	Check sum
h 1111 0111	End of System Exclusive

Notes :

*1 There are two kinds of file names as shown below.

Byte	Description
e 0001 0110	Memory Cartridge M-16C
e 0110 0100	Memory Cartridge M-64C

*2 Summed value of the byte of file name and the check sum must be 0 (7bits).

3.1.3 Data (DAT)

Byte	Description
a 1111 0000	Exclusive status
b 0100 0001	Roland ID #
c 0100 0010	Operation code = DAT
d 0000 nnnn	Unit # = UPPER MIDI basic channel, nnnn = 0 - 15 where nnnn = 1 = channel #
e 0010 0100	Format type (JX-10)
f 0000 tttt	CARTRIDGE MEMORY data (repeated 256 times = 128 bytes)
g 0xxx ssss	Check sum
h 1111 0111	End of System Exclusive

Notes :

*1 CARTRIDGE MEMORY data is sent in four-bit nibbles.

*data format

byte	send data
1 aaaa bbbb	1 0000 aaaa
2 cccc dddd	2 0000 bbbb
	3 0000 cccc
	4 0000 dddd

*2 Summed value of the all bytes in data and the check sum must be 0 (7bits).

3.1.4 Acknowledge (ACK)

Byte	Description
a 1111 0000	Exclusive status
b 0100 0001	Roland ID #
c 0100 0011	Operation code = ACK
d 0000 nnnn	Unit # = UPPER MIDI basic channel, nnnn = 0 - 15 where nnnn = 1 = channel #
e 0010 0100	Format type (JX-10)
f 1111 0111	End of System Exclusive

3.1.5 End of file (EOF)

Byte	Description
a 1111 0000	Exclusive status
b 0100 0001	Roland ID #
c 0100 0101	Operation code = EOF
d 0000 nnnn	Unit # = UPPER MIDI basic channel, nnnn = 0 - 15 where nnnn = 1 = channel #
e 0010 0100	Format type (JX-10)
f 1111 0111	End of System Exclusive

3.1.6 Communication error (ERR)

Byte	Description
a 1111 0000	Exclusive status
b 0100 0001	Roland ID #
c 0100 1110	Operation code = ERR
d 0000 nnnn	Unit # = UPPER MIDI basic channel, nnnn = 0 - 15 where nnnn = 1 = channel #
e 0010 0100	Format type (JX-10)
f 1111 0111	End of System Exclusive

3.1.7 Rejection (RJC)

Byte	Description
a 1111 0000	Exclusive status
b 0100 0001	Roland ID #
c 0100 1111	Operation code = RJC
d 0000 nnnn	Unit # = UPPER MIDI basic channel, nnnn = 0 - 15 where nnnn = 1 = channel #
e 0010 0100	Format type (JX-10)
f 1111 0111	End of System Exclusive

3.2 Sequence of communication

3.2.1 In the 'Dump' mode.

this unit	message	objective unit
-----	-----	-----
	WSF -----	
	<----- ACK or (RQF)	
	DAT -----	
	<----- ACK	
	:	
	DAT -----	
	<----- ACK	
	EOF -----	
	<----- ACK	

3.2.2 In the 'Load' mode.

this unit	message	objective unit
-----	-----	-----
	RQF -----	
	(<----- WSF	
	ACK -----)	
	<----- DAT	
	ACK -----	
	:	
	DAT -----	
	ACK -----	
	EOF -----	
	ACK -----	

CHANGE INFORMATION

Preventing Sound Leakage
EFF SN 640305 Affected PCB: Module Board

Add 3.3k (R126) in parallel to C112.
This filters out unwanted high harmonics components in a sound.

Making Aftertouch
Adjust-free
EFF SN 695830 Affected PCB: Volume Board
The factory experience proved that the aftertouch sensor needs no adjusting of its output. In order to eliminate unnecessary adjustment and retain positive connection, the trimmerpot, if exists, on VOLUME board should be set at FCCM position or jumper-shorted. Fig. E.

ROM Version
The latest version(July 1986) of ROMs A, B and C is 2.00.
The ROM version number system in the JX-10 is that whenever one of three ROMs is revised, other two ROMs are also renumbered to the new version. The version display program is stored in ROM A only.
The software revision shown in the table below have been done on ROM A only -- ROM B and ROM C of Vers. 1.72-2.00 retain unchanged program.

変更案内

○音もれの防止 SN 640325 から

高い周波数で音もれが発生する場合がありそれを防止するためモジュール・ボードの C 1 1 2 と並列に R 1 2 6 3.3K を追加。

○アフタータッチ調整 VR (ボリューム・ボード 2KB) 削除 (無調整) SN 695850 から

SN 695850 未満の製品は調整 VR を左へ回しきるか、または Fig. E のようにショートしてください。

ROM Version
1986年7月現在 ROM (A), (B), (C) の最新は 2.00 です。

Fig. F に示す変更は ROM (A) についてのみ行われています。従って ROM (B) 及び (C) のプログラムは Ver1.72-2.00 を通じて変わりません。

[注意: ROM バージョン表示について JX-10 では、混乱を避けるため 3 個のいずれかのプログラムが変更された場合、他の 2 個のバージョンも同時に変更されます。]




Fig. E


	Part No.
ROM(A) ASSIGNER BOARD IC6	15179733
ROM(B) LOWER MODULE BOARD IC1	15179732
ROM(C) UPPER MODULE BOARD IC1	15179745

ROM(A) Version No.	Serial Number	改善された症状	What is cured
1.72	Prior to 650679		
1.80	650680 650789	一度も PATCH WRITE モードへ入らずに REWRITE VOICE を行うと、PATCH ナンバーが元とは異なったナンバーに書き変わってしまう。 PATCH MEMORY のエディット時に、ファクタ 17 [KEY MODE] の UPPER WHOLE と LOWER WHOLE とを逆に書き込んでしまう。	When REWRITE VOICE is done without entering PATCH WRITE, the current PATCH NUMBER will be memorized incorrectly. In PATCH MEMORY edit, factor 17 KEY MODE sets [UPPER WHOLE and LOWER WHOLE] reversely.
1.90	650790 673899	キーを押さえた状態で PATCH CHANGE を行うとクリックノイズがある。 MIDI IMPLEMENTATION では、MIDI SW を押しながら電源 SW をいれると下記のメッセージが出力することになっているが、実際には出力しない。 *POLY ON *OMNI OFF TONE EDIT 時に、PATCH ファクタ 18 [TOTAL VOLUME] の値が無視され、TONE パラメータ 61 [VCA LEVEL] の値のみで音量が設定されてしまう。 TONE EDIT 後、TONE RECALL を行っても TONE パラメータ 61 [VCA LEVEL] の値が元の値に戻らない。	Resetting PATCH CHANGE while holding a key(s) induces click noise. Discrepancy in MIDI IMPLEMENTATION: It says "when power is first applied while MIDI switch is being pressed, the following messages are transmitted" [POLY ON and OMNI OFF]. This is not true. With TONE edit, PATCH FACTOR 18 [TOTAL VOLUME] is ignored and the loudness is determined only by TONE parameter 61 [VCA LEVEL]. TONE RECALL after TONE edit cannot recall parameter 61 [VCA LEVEL].
2.0	673900 UP	以下の設定時に、LOWER 側の設定が UNISON (1キーについて 2 モジュール発音する。)であるにもかかわらず、3 キー中 2 つのキーが単音で発音してしまう。 KEY MODE : DUAL UPPER ASSIGN : UNISON 以外 LOWER ASSIGN : UNISON HOLD ペダルを踏み込み、アフタータッチをかけながら HOLD ペダルを離す。 その後、アフタータッチをかけないようにしてキーを押しても、LOWER モジュールのみがアフタータッチ発音してしまう。 [但し、その後一度でもアフタータッチをかけると正常にもどる。]	Although set at UNISON, two among three keys in LOWER keyboard are assigned only one voice each. Either of the following settings will see the problem. KEY MODE: DUAL LOWER ASSIGN: UNISON UPPER ASSIGN: other than UNISON When a key is after-touched before HOLD pedal is released, all subsequent non-aftertouch keys will have the aftertouch effect on lower modules even if HOLD pedal has been kept unpressed. Once any key is played aftertouch this condition returns to normal.


IC DATA

HD63B03RP

Pin Configuration
(Top View)




Block Diagram




μPD8155HC

Pin Configuration
(Top View)




Block Diagram




MM5437

Pin Configuration
(Top View)



Block Diagram



訂正及び追加
CHANGE, CORRECTION & SUPPLEMENT

下図の箇所を修正願います。








Schematic Diagram Correction

6 ページ

Page 6

ASSIGNER BOARD

() = LOCATION



ASSIGER BOARD










(W-38)

9 ページ


Page 9

MODULE BOARD


Schematic Diagram Correction




Schematic Diagram Correction



Schematic Diagram Correction



JACK BOARD



下記注意文は北欧諸国向専用です。

The labels below must be attached to the JX-10 service notes that is to be referenced in DNS ruling countries.

ADVARSEL!

Lithiumbatteri. Eksplosionsfare.
Udskiftning må kun foretages af en sagkyndig,
og som beskrevet i servicemanual.

Lithium batteri må kun udskiftes med samme type
og fabrikat.

VARNING!

Lithiumbatteri. Explosionsrisk.
Får endast bytas av behörig servicetekniker.
Se instruktioner i servicemanualen.

Lithium batteri för endast ersättes med samma typ
och fabrikat.

ADVARSEL!

Lithiumbatteri. Fare for eksplosion.
Må bare skiftes af kvalificeret tekniker som
beskrevet i servicemanualen.

Lithium batteri må kun udsiftes med samme type
og fabrikat.

VAROITUS!

Lithiumparisto. Rajahdysvaara.
Pariston saa vaihtaa ainoastaan
alan ammattimies.

Kun vaihat lithium pariston KAYTA saman valmistajan
samaa tyyppiä.