

**【Timbre Sound Chart】 (Multi Timbre Mode)**

**Group A**

| PC  | Tm #  | To # | Tone Name   | P | PC  | Tm #  | To # | Tone Name    | P |
|-----|-------|------|-------------|---|-----|-------|------|--------------|---|
| 001 | C-A11 | c01  | Indo Pipes  | 4 | 033 | C-A51 | c33  | Voxy Pard    | 3 |
| 002 | C-A12 | c02  | Ethnic Syn  | 3 | 034 | C-A52 | c34  | D-50 Vox     | 4 |
| 003 | C-A13 | c03  | Zip Lead    | 4 | 035 | C-A53 | c35  | Syn - Choir  | 2 |
| 004 | C-A14 | c04  | Calliope    | 4 | 036 | C-A54 | c36  | Rezin Choir  | 4 |
| 005 | C-A15 | c05  | Feed Back   | 3 | 037 | C-A55 | c37  | Chorus Mix   | 2 |
| 006 | C-A16 | c06  | Vocodr Dirt | 4 | 038 | C-A56 | c38  | Birthy Pard  | 4 |
| 007 | C-A17 | c07  | Syn Lead 1  | 2 | 039 | C-A57 | c39  | Harmonium    | 2 |
| 008 | C-A18 | c08  | Coolphone   | 3 | 040 | C-A58 | c40  | Glass Voice  | 4 |
| 009 | C-A21 | c09  | Syn Lead 2  | 3 | 041 | C-A61 | c41  | St. Elm Bell | 4 |
| 010 | C-A22 | c10  | Birthy Harm | 4 | 042 | C-A62 | c42  | Drop Hit 2   | 3 |
| 011 | C-A23 | c11  | Stab Pipes  | 4 | 043 | C-A63 | c43  | Toy Hammer   | 2 |
| 012 | C-A24 | c12  | Steel       | 2 | 044 | C-A64 | c44  | Cutting EG   | 3 |
| 013 | C-A25 | c13  | Soprano Max | 2 | 045 | C-A65 | c45  | Rhoads Gird  | 4 |
| 014 | C-A26 | c14  | Holly Pipe  | 2 | 046 | C-A66 | c46  | Backin' Syn  | 2 |
| 015 | C-A27 | c15  | Growlead    | 2 | 047 | C-A67 | c47  | Heaven       | 4 |
| 016 | C-A28 | c16  | Digi Dance  | 4 | 048 | C-A68 | c48  | Bell Tower   | 2 |
| 017 | C-A31 | c17  | ORCH        | 4 | 049 | C-A71 | c49  | Stream       | 4 |
| 018 | C-A32 | c18  | Cellos Gird | 4 | 050 | C-A72 | c50  | Kankyo       | 4 |
| 019 | C-A33 | c19  | Jarrecotic  | 4 | 051 | C-A73 | c51  | Arpeggi Box  | 4 |
| 020 | C-A34 | c20  | JX Strings  | 2 | 052 | C-A74 | c52  | Uguisu       | 4 |
| 021 | C-A35 | c21  | Glide Str   | 4 | 053 | C-A75 | c53  | Tom & Jery   | 4 |
| 022 | C-A36 | c22  | Slow Str    | 2 | 054 | C-A76 | c54  | Raindrops    | 2 |
| 023 | C-A37 | c23  | Marcatics   | 4 | 055 | C-A77 | c55  | SOL          | 4 |
| 024 | C-A38 | c24  | Stardust    | 4 | 056 | C-A78 | c56  | Space        | 2 |
| 025 | C-A41 | c25  | Koto Brass  | 4 | 057 | C-A81 | c57  | Jet Stream   | 4 |
| 026 | C-A42 | c26  | Soft Pad    | 2 | 058 | C-A82 | c58  | Underground  | 1 |
| 027 | C-A43 | c27  | Analog Brs  | 2 | 059 | C-A83 | c59  | Sparcle      | 4 |
| 028 | C-A44 | c28  | Xylo Brass  | 4 | 060 | C-A84 | c60  | Fall         | 4 |
| 029 | C-A45 | c29  | Velo Sweep  | 2 | 061 | C-A85 | c61  | SHIFT        | 3 |
| 030 | C-A46 | c30  | Clasic Horn | 4 | 062 | C-A86 | c62  | Cicadas      | 2 |
| 031 | C-A47 | c31  | Future Pad  | 4 | 063 | C-A87 | c63  | Taxiway      | 4 |
| 032 | C-A48 | c32  | Aurora      | 3 | 064 | C-A88 | c64  | OFF & INIT   | 0 |

**Group B**

|     |       |     |              |   |     |       |     |             |   |
|-----|-------|-----|--------------|---|-----|-------|-----|-------------|---|
| 065 | C-B11 | a01 | Acou Piano 1 | 3 | 097 | C-B51 | b03 | Chorale     | 3 |
| 066 | C-B12 | a04 | Honky - Tonk | 3 | 098 | C-B52 | b05 | Soundtrack  | 4 |
| 067 | C-B13 | a05 | Elec Piano 1 | 3 | 099 | C-B53 | b06 | Atmosphere  | 4 |
| 068 | C-B14 | a06 | Elec Piano 2 | 3 | 100 | C-B54 | b07 | Warm Bell   | 4 |
| 069 | C-B15 | a09 | Elec Organ 1 | 4 | 101 | C-B55 | b09 | Echo Bell   | 3 |
| 070 | C-B16 | a12 | Elec Organ 4 | 1 | 102 | C-B56 | b12 | Echo Pan    | 2 |
| 071 | C-B17 | a15 | Pipe Organ 3 | 2 | 103 | C-B57 | b14 | Reso Synth  | 2 |
| 072 | C-B18 | a16 | Accordion    | 2 | 104 | C-B58 | b16 | Vibe String | 4 |
| 073 | C-B21 | a18 | Harpsi 2     | 2 | 105 | C-B61 | b17 | Syn Lead 1  | 4 |
| 074 | C-B22 | a20 | Clav 1       | 3 | 106 | C-B62 | b20 | Syn Lead 4  | 2 |
| 075 | C-B23 | a24 | Celesta 2    | 2 | 107 | C-B63 | b21 | Syn Bass 1  | 3 |
| 076 | C-B24 | a31 | Harp 2       | 2 | 108 | C-B64 | b24 | Syn Bass 4  | 3 |
| 077 | C-B25 | a30 | Pizzicato    | 3 | 109 | C-B65 | b25 | Acou Bass 1 | 2 |
| 078 | C-B26 | a29 | Contrabass   | 2 | 110 | C-B66 | b27 | Elec Bass 1 | 2 |
| 079 | C-B27 | a27 | Cello 1      | 3 | 111 | C-B67 | b29 | Slap Bass 1 | 2 |
| 080 | C-B28 | a26 | Violin 2     | 2 | 112 | C-B68 | b31 | Fretless 1  | 4 |
| 081 | C-B31 | a35 | Strings 3    | 2 | 113 | C-B71 | b37 | Guitar 1    | 3 |
| 082 | C-B32 | a36 | Stringa 4    | 3 | 114 | C-B72 | b38 | Guitar 2    | 3 |
| 083 | C-B33 | a37 | Brass 1      | 4 | 115 | C-B73 | b41 | Koto        | 2 |
| 084 | C-B34 | a40 | Brass 4      | 4 | 116 | C-B74 | b42 | Shamisen    | 2 |
| 085 | C-B35 | a42 | Trumpet 2    | 2 | 117 | C-B75 | b43 | Jamisen     | 2 |
| 086 | C-B36 | a43 | Trombone 1   | 3 | 118 | C-B76 | b47 | Sitar       | 4 |
| 087 | C-B37 | a46 | Fr Horn      | 2 | 119 | C-B77 | b45 | Shakuhachi  | 4 |
| 088 | C-B38 | a48 | Tuba         | 2 | 120 | C-B78 | b48 | Steel Drum  | 4 |
| 089 | C-B41 | a49 | Flute 1      | 4 | 121 | C-B81 | b33 | Vibe        | 2 |
| 090 | C-B42 | a52 | Recorder     | 2 | 122 | C-B82 | b35 | Marimba     | 3 |
| 091 | C-B43 | a54 | Bottleblow   | 4 | 123 | C-B83 | b36 | Xylophone   | 2 |
| 092 | C-B44 | a56 | Whistle      | 2 | 124 | C-B84 | b56 | Tube Bell   | 4 |
| 093 | C-B45 | a57 | Sax 1        | 2 | 125 | C-B85 | b54 | Triangle    | 2 |
| 094 | C-B46 | a60 | Clarinet 1   | 2 | 126 | C-B86 | b53 | Timpani     | 2 |
| 095 | C-B47 | a62 | Oboe         | 3 | 127 | C-B87 | b62 | Insect      | 2 |
| 096 | C-B48 | a64 | Harmonica    | 2 | 128 | C-B88 | b51 | Revrse Cym  | 2 |

PC: Program Change Number Tm #: Timbre Number To #: Tone Number P: Number of Partial